

# ASSEMBLY INSTRUCTIONS FOR ROOFING MEMBRANES



Unfold the membrane parallel to the eaves with the inscriptions upwards.



Tension the membrane lightly and fix to the rafter with staples or wide head nails (roofing nails).



Nail the counter-battens in such a way as to cover the points of the membrane punctured with staples or roofing nails. In order to seal the membrane, it is recommended (in case of roofs with pitches below 20° it is required) to apply sealing tape (e.g. Corotop Pur) on the pressure side of the membrane before installing a counter-batten.

The height of counter-battens must be selected according to DIN 4108-3:1996.



Further membrane strips should be installed with a suitable overlap, according to the imprint on the membrane.



In order to eliminate draughts in the roof baffle, it is recommended (in case of roofs with pitches below 20° it is required) to bond the membrane overlaps with with the double-sided tape (e.g. Corotop Mix) or the adhesive strips integrated in the membrane and glued one to another (PLUS version).